



A" = SIZE OF SEWER MAIN

NOTES:

1. ALL FITTINGS UP TO END OF STACK TO BE PRESSURE FITTINGS.
2. ALL FITTINGS AT END OF STACK TO BE TO BE SCH 40 OR PRESSURE FITTINGS AT CONTRACTOR'S OPTION.

THE CITY OF ROSENBERG, FORT BEND COUNTY, TEXAS
DEPARTMENT OF PUBLIC WORKS

*SANITARY SEWER FAR SIDE
STACK CROSSOVER*

DESIGN: CAK	CAD: STAFF	SCALE: NTS	DATE: 12/10
			DRAWING: S-100b